

Interior Relay Box			
Relay Number	Details	Loads	Schematic
RL001	35A 1 Contact BR	Blower Heater	
RL002	20A 1 Contact GN	FCM & HVAC POWER	
RL003	35A 1 Contact BR	ECO Mode	
RL004	20A 1 Contact GN	Mirrors and Rear Screen Heater	
RL005	20A 2 Contact GY	Front Wash Pump	
RL006	20A 2 Contact GY	Rear Wash Pump	

RL007	35A 1 Contact BR	Front Window Winder	
RL008	35A 1 Contact BR	Rear Window Winder	
RL009	20A 2 Contact GY	Rear Wiper Motor	
RL010	20A 2 Contact GY	Master Unlock	
RL011	20A 2 Contact GY	Master Lock	