



Interior Relay Box			
Relay Number	Details	Loads	Schematic
<b>RL001</b>	35A 1 Contact BR	Blower Heater	
<b>RL002</b>	20A 1 Contact GN	FCM & ICN POWER	
<b>RL003</b>	35A 1 Contact BR	ECO Mode	
<b>RL004</b>	20A 1 Contact GN	Mirrors and Rear Screen Heater	
<b>RL005</b>	20A 2 Contact GY	Front Wash Pump	
<b>RL008</b>	35A 1 Contact BR	Rear Window Winder	

<b>RL009</b>	20A 2 Contact GY	Trunk Lid Motor	
<b>RL010</b>	20A 2 Contact GY	Master Unlock	
<b>RL011</b>	20A 2 Contact GY	Master Lock	